




The ALLAN HOLDSWORTH Signature OD/Boost was created in conjunction with Allan to address his personal needs in both live and studio situations. Below is an explanation of the pedals functions.



DRIVE

BOOST

VOLUME - THE VOLUME CONTROL WILL ONLY EFFECT THE VOLUME OF THE DRIVE UNLESS YOU CASCADE THE BOOST INTO THE DRIVE

GAIN - THE GAIN CONTROL WILL ONLY EFFECT THE GAIN OF THE DRIVE SIDE UNLESS YOU CASCADE THE BOOST INTO THE DRIVE

BASS - THE BASS CONTROL WILL ONLY EFFECT THE DRIVE SIDE UNLESS YOU CASCADE THE BOOST INTO THE DRIVE

TREBLE - THE TREBLE CONTROL WILL ONLY EFFECT THE DRIVE SIDE UNLESS YOU CASCADE THE BOOST INTO THE DRIVE.

BOOST - THE BOOST CONTROL EFFECTS ONLY THE VOLUME OF THE BOOST SIDE UNLESS YOU CASCADE THE BOOST INTO THE OVERDRIVE.

L SWITCH - THE "L" SWITCH POSITION WHEN ENGAGED WILL EMPHASIZE THE LOWS AND WILL ONLY EFFECT THE BOOST SIDE UNLESS YOU CASCADE THE BOOST INTO THE DRIVE

H SWITCH - THE "H" SWITCH POSITION WHEN ENGAGED WILL EMPHASIZE THE HIGHS AND WILL ONLY EFFECT THE BOOST SIDE UNLESS YOU CASCADE THE BOOST INTO THE DRIVE

F SWITCH - THE "F" SWITCH POSITION INDICATES FULL BOOST MODE AND WILL ONLY EFFECT THE BOOST SIDE UNLESS YOU CASCADE THE BOOST INTO THE DRIVE.

C SWITCH - THE "C" SWITCH POSITION INDICATES CLEAN BOOST MODE AND WILL ONLY EFFECT THE BOOST SIDE UNLESS YOU CASCADE THE BOOST INTO THE DRIVE.

T SWITCH - THE "T" SWITCH INDICATES TREBLE BOOST MODE AND WILL ONLY EFFECT THE BOOST SIDE UNLESS YOU CASCADE THE BOOST INTO THE DRIVE.

PLEASE PAY ATTENTION TO THE LINES ON THE FACE PLATE. EACH LINE INDICATES FUNCTIONS THAT ARE ASSOCIATED WITH THE BOOST. THESE RESPECTIVE FUNCTIONS DO NOT RELATE TO THE DRIVE SIDE UNLESS THE BOOST IS CASCADED INTO THE DRIVE. THE PEDAL CAN BE OPERATED AS 2 DISCRETELY INDEPENDENT UNITS OR CAN BE CASCADED FOR MORE DRAMATIC DRIVE SOUNDS.

Warranty

Rockett Pedals LLC. will repair or replace, at its discretion, defective workmanship or materials on all new Rockett Pedals products directly or through; the selling dealer or an authorized service technician, for one year from the date of purchase at no cost to the original purchaser. Repair and replacement parts installed will be warranted for the unexpired portion of the original warranty term.

Before sending product in for repair please contact us at chris@rockettpedals.com or jay@rockettpedals.com. Or call 760-419-1345.

This warranty does not cover shipping costs, product appearance or damages caused by accident, abuse, misuse or alteration.

A dated sales slip or order number (issued by a tech, dealer or Rockett Pedals) must accompany a product being returned for warranty service. Repairs without a return authorization number will be refused. Please allow 4 weeks for warranty service. For more information please contact Rockett Pedals www.rockettpedals.com or 760-419-1345. No other warranty is expressed or implied.

9V AC ADAPTER

